

# ROGER CENTRALI DI CONTROLLO

**centrale per 1 motore 230Vac**  
**H70/104AC - H70/105AC**

IT - Istruzioni e avvertenze per l'installatore - pag.2

EN - Instruction and warnings for the installer - pag.22

DE - Anleitungen und Hinweise für den Installateur - S.42

ES - Instrucciones y advertencias para el instalador - pag.63

FR - Instructions et mises en garde pour l'installateur - page 84

PT - Instruções e advertências para o instalador - pág.105

	pag.
1	Introduction to the instructions and warnings 24
2	Product technical characteristics 24
3	Product description 25
4	Description of connections and fuses 25
4.1	Motors connection and limit switch 26
4.2	Standard limit switch configuration 26
4.3	Standard photocells configuration 26
4.4	Standard safety edges configuration 27
5	Radio receiver plug-in 27
6	Display operation modes 27
6.1	Commands and safety protections status mode 27
6.2	Parameters mode 27
6.2.1	Changing a parameter 28
6.2.2	Restoring standard factory parameters 28
6.2.3	Simplified/extended parameters mode change 29
6.3	Standby mode 29
6.4	TEST mode 29
7	Installation 30
7.1	Stroke programming sequence 30
7.2	Programming sequence to time work without encoder and with safety edge 30
7.3	Programming sequence to time work without encoder and without safety edge 31
8	PHOTOCELL TEST mode 31
9	Error reporting 31
10	Position recovery mode 31
11	Operating mode extended 32
12	Inspection 41
13	Maintenance 41
14	Disposal 41
15	Pictures and schemes 126

## 1 Introduction to the instructions and warnings

**This manual is only intended for personnel qualified to perform the installation.**

**No information contained in this document may be considered of interest to the end user.**

**This manual refers to controls panels H70/104AC and H70/105AC for automation composed by one single-phase asynchronous 230Vac motor.**



**WARNINGS**



**SHOCK HAZARD**

Read the instructions carefully before starting the installation.

To avoid the risk of electrocution and physical injury always cut the power before intervening on the device. The installation must only be carried out by qualified service personnel according to applicable regulations.

Use wires with suitable currents and voltages ratings to make the connections; observe the product's technical characteristics. Check the conformity of the grounding and the continuity between the earth on the motor side and the control unit's terminal block.

The loads connected to the COR (courtesy) and LAM (flashing) contacts must be protected by a 5x20 fast-acting fuse with a maximum value of 1A 250V.

If you connect an electric lock, do not feed it with the built-in power supply for external devices but with a proper external power supply.

If You take off the fuse for the protection of 24Vac (F2), it powers off the photocells and relays but the power remains on the control part and the display shows **24 AC** blinking. In this way it is not possible to reset the microcontroller. If it is necessary, for example after modifying the parameter of the gate structure (e.g. encoder and limit switches), You have to cut off the power and wait until the display switches off, after that You have to power on again the control unit.

## 2 Product description

The **H70/104AC** control unit is dedicated to the control of 1 asynchronous motor for pre-wired ROGER automations such as sliding and overhead types.

The **H70/105AC** control unit can drive any asynchronous motor which is within the specifications.

Using motors with encoder, the control unit can obtain the information on the position of the leaf and detect impact situations.

You can connect photocells, safety edges, pushbutton panels, key selectors, a flashing light, a radio receiver, an open gate light, an electric lock, a courtesy light and a clock. There are two configuration levels: a simple one which satisfies most of the installations and an extended (advanced) one where it is possible to extensively customise the behaviour of the automation.

### 3 Technical product characteristics H70/104AC - H70/105AC


SUPPLY VOLTAGE	230Vac ± 10% 50Hz
MAXIMUM POWER CONSUMPTION	1300W
CONNECTABLE MOTORS	1
POWER SUPPLY MOTORS	230Vac
MOTOR TYPES	single-phase asynchronous
MOTOR CONTROL TYPE	phase adjustment with triac
RATED POWER MOTOR	600W
MAXIMUM POWER FLASHING LIGHT	40W 230Vac - 25W 24Vac/dc (pure contact)
MAXIMUM POWER COURTESY LIGHT	100W 230Vac - 25W 24Vac/dc (pure contact)
GATE OPEN LIGHT POWER	2W (24Vac)
ACCESSORY OUTPUT POWER	6W (24Vac)
OPERATING TEMPERATURE	-20°C ... +60°C
DEGREE OF PROTECTION	IP00
PRODUCT DIMENSIONS	Dimension in mm. 98 x 141 x 40 Weight: 0,48 Kg

### 4 Description of connections and fuses

**Figure 1** shows the connection diagram for the power supply, motors and fuses.

The board has two quick type 5x20 mm fuses, **F1** of 6,3A 250V (F6,3A) and **F2** of 315mA 250V (F315mA).

**Figures 2 and 3** show the connections of the inputs and the outputs; below the description of the individual terminal blocks:

- 1** **L** (Line), power supply input 230Vac 50Hz
- 2** **N** (Neutral), power supply input 230Vac 50Hz
- 3** **Earth** connection – mandatory to meet the line safety and filtering requirements
- 4** **AP**, 230Vac motor output: opening
- 5** **CM**, 230Vac motor output: common
- 6** **CH**, 230Vac motor output: closing
-  Connect a capacitor using the value indicated in the motor instructions.
- 7,8** **COR**, courtesy light (pure contact): maximum voltage 230Vac, see technical features. Alternatively you can connect an electric lock if you set parameter **79 99**.
- 9,10** **LAM**, flashing (pure contact): maximum voltage 230Vac, see technical features
- 11** **24Vac**, power supply for external devices (6W, maximum current 250 mA, to be reduced to 200mA in the case of devices that do not have an on-board rectifier bridge)
- 12** **SC**, gate open light (24Vac, 2W); alternatively, you can connect the power supply for the photocells transmitters (TX) to this terminal bloc (provided that you set parameter **AB** to

the value **02**, in extended mode) to have the “photocell test” functionality

- 13** **COM**, common to low voltage inputs and outputs
- 14** **FT2**, photocell 2 (N.C. contact) <sup>(a)</sup>
- 15** **FT1**, photocell 1 (N.C. contact) <sup>(a)</sup>
- 16** **COS2**, safety edge 2 (N.C. contact or 8.2kOhm) <sup>(a)</sup>
- 17** **COS1**, safety edge 1 (N.C. contact or 8.2kOhm) <sup>(a)</sup>
- 18** **ST**, STOP command (contact N.C.) <sup>(a)</sup>
- 19** **PP**, step-by-step command input
- 20** Receiving antenna cable braiding
- 21** Antenna cable pole for plug-in radio receiver (if you are using an external antenna, connect it with RG58 cable)
- 22** **ORO**, clock command input
- 23** **PED**, pedestrian opening command input (N.O. contact): factory set it opens the leaf to 30% of the limit switch
- 24** **CH**, closing command input (contact N.O.)
- 25** **AP**, opening command input (contact N.O.)
- 26** **COM**, common to low voltage inputs and outputs
- 27,28** **COM**, common to low voltage inputs and outputs

Encoder, limit switches and unlock switch terminal blocks, on the top left of the board (**figure 4**), will vary depending on the board model (**H70/104AC** o **H70/105AC**).

**H70/104AC** has 3 white connectors, it only fits ROGER automations where the control unit is built into the motor and is pre-wired. The connectors description is below:

- SB** Microswitch wiring for motor unlocking (contact N.C): inhibits the movement of the

automation. <sup>(a)</sup>

**FC** Wiring motor limit switches (N.C. contacts.)



**ENC** Wiring ROGER motor encoder <sup>(b)</sup>

**H70/105AC** has a screw terminal block for universal use, the description of the individual terminals is below:

- 29** **+5Vdc**, only for ROGER motor encoder power supply
- 30** **24Vac**, only for ROGER motor magnetic limit switches power supply
- 31** **FC1**, limit switch 1 input (N.C.contact). Function set by parameter **8-** (**72** in extended mode) <sup>(c)</sup>
- 32** **FC2**, limit switch 2 input (N.C. contact). Function set by parameter **8-** (**72** in extended mode) <sup>(c)</sup>
- 33** Do not connect
- 34** **ENC**, ROGER motor encoder signal <sup>(b)</sup>
- 35** **COM**, common for low voltage inputs and outputs; negative for motor encoder power supply.

#### IMPORTANT NOTES

- <sup>(a)</sup> All of the safety protections not installed that provide for a normally closed (N.C.) contact must be electrically bridged to the COM terminals (shared by inputs/outputs), or deactivated by adjusting the appropriate extended parameters (par. **50, 51, 53, 54, 73, 74** – see paragraphs 4.2, 4.3 and 4.4).
- <sup>(b)</sup> The optical encoder is enabled at the factory; it is connected whether it is magnetic or not, acting on parameter **6-** (**75** in extended mode), selecting the appropriate value for the motor used.
- <sup>(c)</sup> If the limit switches are not present disable them by acting on parameter **8-** (**72** in extended mode), not jumper. The function of the limit switch inputs depends on parameter **0-** (**71** in extended mode), factory set to **01**, and is shown below:

	<b>FC1 -&gt; FCA</b> limitswitch open	<b>FC2 -&gt; FCC</b> limitswitch close
	<b>FC1 -&gt; FCC</b> limitswitch close	<b>FC2 -&gt; FCA</b> limitswitch open

### 4.1 Motor connection and limit switches

For **H70/104AC** the motor and the limit switches are pre-wired and do not require interventions. In case you need to reverse the direction of rotation you

should not modify the wiring (motor and limit switch) but act on parameter **0-** (**71** in extended mode).

To connect **H70/105AC** to the motor you have to use a cable 4 x 1.5 mm<sup>2</sup>. The limit switches, if present, can be connected to the switch with a 4x0,5mm<sup>2</sup>. Alternatively, whenever present in the motor, **they can be used to cut the power supply to the motor** when the leaf reaches the limit position: in this situation, the limit switches must not be connected to the input terminals 31 and 32 but they are connected in series to the AP output (if opening limit switch), CH (if closing limit switch). With this type of connection, the motor stops upon activation of the limit switch, but if the control is based on time (disabled encoders) the relays and the flashing only turn off when the programmed work time is over.







### 4.2 Standard limit switch configuration

Inputs **FC1** and **FC2** re enabled as factory standard. If they are not present, or if they are used to cut the phase of the motor as described in the previous paragraph, set parameter **8-** **00** (in extended mode **72 00**), do not jumper the inputs. By setting this parameter to **02** you can only enable the limit switch when opening.

### 4.3 Standard photocells configuration

Inputs **FT1** and **FT2** are enabled as a production standard.

Below is the standard configuration of the photocells and related parameters of the extended mode:

FT1 ignored during opening	
FT1 interruption during closure causes a reversal of motion, i.e. it opens	
Allows for the activation of the motors to opening even if FT1 is obscured	
FT2 interruption during opening causes a stop; once the beam is released it continues to open	
FT2 interruption during closing causes a stop; once released the beam is reversed, i.e. it opens	
Allows for the activation of the motors opening even if FT2 is obscured	



#### IF THE PHOTOCELLS 1 IS NOT INSTALLED

Set **50 00** and **51 00**

#### IF THE PHOTOCELLS 2 IS NOT INSTALLED

Set **53 00** and **54 00**

Or electrically bridge their terminals with the COM terminal block.

## 4.4 Standard safety edges configuration

Inputs **COS1** and **COS2** are disabled as factory standard.

To enable and configure them please refer to the parameters in extended mode **73** and **74**.

## 5 Radio receiver plug-in

The receiver (see **figure 1**) provides two functions for radio remote control that are assigned in the following way as a production standard:

- PR1** step-by-step control (can be changed by adjusting parameter **76** of extended mode)
- PR2** command pedestrian opening control (can be changed by adjusting parameter **77** of extended mode)

## 6 Display operation modes


The screen can display the following information, depending on the operating mode the control unit is in:

- COMMANDS AND SAFETY PROTECTIONS STATUS MODE:** the status of the control inputs is shown by two digits on the left, in the two digits on the right the status of the safety protections is shown by two digits on the right. As soon as the display control unit is powered in this mode. In any other condition just press the UP or DOWN key several times until it displays the status of the inputs. The status of the inputs is found after the last parameter and before the first parameter. See section 6.1 for a full description.
- PARAMETERS MODE:** the two digits on the left will display the name of the parameter, the two digits on the right display its numerical value. See section 6.2 for a full description.
- MODALITA' STANDBY:** makes the LED "POWER" flash which indicates the presence of the power supply voltage (decimal point of the furthest left digit). See section 6.3 for a full description
- TEST MODE:** the two digits on the left display

the name of the active command (for 5 seconds, then it goes off), the two figures on the right display, flashing, display the number of the safety protection terminal block possibly in a state of alarm. To exit this mode press the TEST button. See section 6.4 for a full description.

## 6.1 Commands and safety protections

The inputs are shown on the display in the following way:




If the input is closed the corresponding segment comes on. The segments corresponding to the controls will normally be turned off (normally open contacts), will be turned on upon receipt of a command. The segments corresponding to the safety protections installed must be turned on (normally closed contacts); if they are turned off it means that they are in a state of alarm.

**SAFETY PROTECTIONS DISABLED BY PARAMETER:** the corresponding LED segment flashes.

**NO SAFETY PROTECTIONS:** the segment never appears

## 6.2 Parameters mode



- UP** next parameter
- DOWN** previous parameter
- +** increases the parameter value by 1
- decreases the parameter value by 1
- PROG** programming the stroke (see par. 7)
- TEST** enables test mode (see par. 6.4)

## 6.2.1 Changing a parameter

Using the UP and DOWN buttons to view the parameter to be changed, then with the + and - buttons change its value (the number on the right starts flashing). While holding down a button, after one second quick sliding is activated, allowing you to change the parameter quicker. To save the value set on the display, wait a 4 seconds, or move to another parameter with the UP and DOWN buttons: the whole display will flash quickly indicating that the parameter has been saved.

**NOTE: Changing the numerical value of the parameters with the + and - buttons is only possible with the engine stopped, while consultation of the parameters is always possible.**

The sequence of parameters in the mode simplified

is shown in the table below.

**ATTENTION!** Some parameters (0-, 8- e b-) are particularly criticals, and change them with the system already started, may cause malfunction; to give effect to the change in their value you have to disconnect the power supply and then restart the system and re-programming the stroke.

## 6.2.2 Restoring standard factory parameters

**N.B.: this procedure is only possible if you have not entered the password to protect your data.**

Turn off the control unit, simultaneously press and hold the UP and DOWN buttons then turn on again and keep up pressing the buttons: after 4 seconds the display will show the writing **FESE** flashing, which indicates that the values have been restored.

STANDARD PARAMETER AND VALUE	FUNCTION	VALUE ON DISPLAY	DESCRIPTION
0- 00	Position of the motor with respect to the gap	00	motor on the LEFT with respect to the gap looking from inside
		01	motor on the RIGHT with respect to the gap looking from inside
	Automatic reclosing	00	deactivated
		01 - 15	number of attempts to reclose (interrupted by photocell) before finally staying opened
		99	always tries to reclose
2- 30	Pause time	00 - 90	seconds of pause
		92 - 99	2 minutes...9 minutes of pause
3- 00	Emergency blackout	00	deactivates the reclosing when power returns
		01	enables the reclosing when power returns
4- 00	“generator” mode	00	Deactivated
		01	enables a digital filtering for additional power from generators
5- 00	Pre-flashing	00	deactivated
		01 - 10	pre-flashing seconds
		99	5 seconds of pre-flashing only when closing
6- 00	Step-by-step mode	00	open stop close stop open stop close ...
		01	condominium, refreshes the pause time
		02	ccondominium, closes from completely open
		03	open close open close
		04	open close stop open
7- 00	Flashing activation	00	fixed
		01	one flash per second
		02	normal flash when opening, fast when closing
8- 00	Enabling limit switch	00	no limit switch connected
		01	limit switch on opening and closing connected
		02	only limit switch on opening connected
9- 05	Normal operating torque	01 - 08	1 minimum torque ... 8 maximum torque
A- 00	Torque during slowdown	01 - 08	1 minimum torque ... 8 maximum torque
b- 01	Select encoder	00	Disabled
		01	optical encoder
		02	magnetic encoder

### 6.2.3 Simplified/extended parameters


The control unit provides two modes of configuration: extended or simplified.

In extended mode the installer can change a lot of parameters, but you need a more in-depth knowledge of the product.

Simplified mode has been designed for easy of installation, only a few parameters can be changed. It is the recommended mode for an installer who is not very familiar with the product and who does not need special configurations.

#### WARNING!

The product leaves the factory set in simplified mode.



If you want to go to extended mode hold the UP and DOWN buttons both for 4 seconds, after this time the first of the parameters of the extended version will be displayed on the display, which is highlighted:

- by the presence of two decimal points on the first two left digits (representing the parameter number)
- of the letter *A* in parameters less than 10, to distinguish them from those of the simplified version (which are different)

N.B.: The operation can be performed several times, switching from one mode to another at will.

The table in paragraph 11 contains the parameters for extended mode

**N.B.: the sequence of parameters for simplified mode is not the same as that of extended mode, therefore always refer to the instructions or the label on the inside of the cover.**

### 6.3 Standby mode

After 30 minutes of inactivity, the control unit enters standby mode, and the display only indicates a flashing dot. The activation of standby automatically


resets the simplified parameters mode.

The mode remains at rest on the display, but the control unit is always ready to perform commands; to turn the display back on you have to press one of the buttons UP,DOWN,+,,-.

### 6.4 TEST mode

This is activated by pressing the TEST button, only if the motors are stationary; otherwise, the TEST button performs a STOP command and only the subsequent operation of the button enables test mode.

The display is as follows:



Allows you to visually inspect the activation of the commands and the safety protections: upon each of their activations, the control unit briefly activates the flashing and the Gate Open Light (terminal block no. **12**, SC)

The display indicates:

- the command activated, in fixed letters (on the left-hand side, for a period of 5 seconds)
- in a flashing number, the safety protection terminal block in a state of alarm (right part, displayed as long as the safety protection is in a state of alarm). They are instead represented by letters unlocking it (given that it does not have a terminal block number) and limit switches (given that inputs **FC1** and **FC2** change their function in relation to the setting of parameter **71**).

If no safety protection is in a state of alarm **00**, is displayed, therefore the control unit is enabled to perform the commands; the only exception is when a limit switch is activated, which appears but does not constitute a barrier to issuing a command.

After 10 seconds of inactivity it will return to commands and safety protections status mode. To immediately exit test mode just press the “TEST” button again.

## 7 Installation

It is necessary to programme the stroke to allow the correct operation of the control panel.

**WARNING!** Before proceeding, make sure that:

- The direction of rotation of the motor has been correctly selected with the parameter **0- (7 l** in extended mode)
- For safety position the leaf in an intermediate position in such a way as to have time to stop the motor in case it moves in the wrong direction.
- The safety protections connected are at rest and those not present are electrically bridged or excluded by the related parameter.
- You cannot enter programming mode if one of the safety protections is active. The display changes to TEST mode and displays the input that is in a state of alarm and which prevents you from proceeding.
- You cannot enter programming mode if you have enabled the “man present” mode (para. **A701**), **APPE** will appear on the display.

**NOTE:**

- It is mandatory to have a gate stop when opening and closing.
- 6-pole motors turn at a slower rate than 4-pole ones: for them, therefore, parameter **4 l** must have maximum value **0 l** (factory standard). In addition, parameters **42** and **43** must have a value of less than **60**.
- **Programming is interrupted (with error message **APPE**) in the following situations:**
  - The TEST button is pressed.
  - One of the safety protections (photocells, safety edges, STOP button) is turned on.

In such an event you have to repeat the programming of the stroke.

### 7.1 Stroke programming sequence with encoder enable

**WARNING!**

- The stroke measurement takes place during the closing phase.
- If the limit switch are connected, the motion stops when they are activated, otherwise it stops on the gate stop.

- Programming is performed with the speed slowed down as set in parameter **4 l** in extended mode.

To enter programming press the PROG button for 4 s.: the display will show **APPE**; at this point, you can programme the stroke by pressing the PROG button again, or by pressing the radio control button enabled by the step-by-step function.

**Press PROG (o PP):** programming is performed in a fully automatic way: wait for completion avoiding crossing the ray of the photocells or activating other safety devices (safety edges, stop).

The display shows the indication **AU EO** and starts to open when the leaf is in the fully open position, the writing **AU EO** flashes on the display for 2 seconds indicating that it is going to close again, then the indication **AU EO** stops flashing and the closing manoeuvre starts.

If programming is completed properly, the display returns to the status of the commands and the safety protections.

Otherwise **APPE** (error when learning) appears and programming needs to be repeated.

### 7.2 Programming sequence to time work without encoder and with safety edge

**WARNING!**

- Programming the work time takes place during the closing phase
- The safety time margin is automatically added by the control unit.

To enter programming press the PROG button for 4 s.: the display will show **APPE**; at this point, you can programme the stroke by pressing the PROG button again, or by pressing the radio control button enabled by the step-by-step function.

**Press PROG (or PP):** starts to open **AP l**, appears on the display, when leaf 1 has reached the opening limit switch **PA** appears on the display flashing, after 2 seconds the closing manoeuvre automatically starts and **CH l** appears on the display. Once the closing limit switch has reached the programming is finished.

If programming is completed properly, the display returns to the status of the commands and the safety protections.

Otherwise **APPE** (error when learning) appears and programming needs to be repeated.



### 7.3 Programming sequence to time work without encoder and without safety edge

#### WARNING!!

- Work time programming takes place during the closing phase: in the absence of an encoder and switch limit a bigger time allowance must be programmed, after having stopped (min. 2 seconds - max. 4 seconds) to be sure that the manoeuvre is always completed even in different environmental conditions.

To enter programming press the PROG button for 4 s.: the display will show **AP P-**; at this point, you can programme the stroke by pressing the PROG button again, or by pressing the radio control button enabled by the step-by-step function.

**First press PROG (o PP):** starts to open, the display shows **AP I**.

**Second press PROG (o PP):** when the leaf has reached the opening stop, press the PROG key, thus stopping the motor. PA appears on the display flashing, after 2 seconds the closing manoeuvre starts automatically; **CH I** appears on the display.

**Third press PROG (o PP):** when the leaf has reached the closing stop, leave a margin of 2-4 seconds and press the PROG key, thus stopping the motor: the programming is complete.

If programming is completed properly, the display returns to the status of the commands and the safety protections.

Otherwise **APPE** (error when learning) appears and programming needs to be repeated.

### 8 PHOTOCCELL TEST mode

By connecting the power of the transmitters of the photocells to terminal block **SC** (nr. 12) instead of to terminal no. 11 and by selecting the parameter **AB 02** in the parameters extended mode, the photocells test mode is activated.

For each command issued the control unit turns the photocells off and on and checks that the status of the contact changes correctly: only if this is so will the command activate the motors, otherwise the locked status is maintained given that there is a fault on the photocells.

NOTE: in this mode 24 VDC of voltage is still present in the **SC** terminal block, therefore you can no longer use that output for the gate open light.

### 9 Error reporting

The operating parameters are stored in a non-volatile memory (EEPROM) with appropriate control codes which ensure its validity; an error in the parameters is shown on the display and at the same time the control unit will not allow the command to be activated.

Example: in the case an error occurring in parameter 21, the display would present the folloleaf type of indication: **21EE**.

**EE** indicates the presence of the error, the control unit will be locked until the correct value is restored; you must use the + and - buttons, selecting the numeric value appropriate to the installation, and then save it.

NOTA: in the case of an error in the parameter, the "extended numbering shown in the table in paragraph 11 is always displayed, even if the simplified method has been activated.

The display show **EA EA** when happens an error in the data related to the length of the stroke; it is necessary to run a new programming. It is possible to unlock the display to show the parameters, by pressing the TEST key.

### 10 Position recovery mode

When you see the leaf close at a slower rate than usual and the flashing light is active in a different way than usual, it means that the control unit is retrieving the references: in this situation you have to wait until the flashing has stopped to issue new commands, as it is necessary to let the manoeuvre finish.

If you do not let the manoeuvre finish, the movement of the leaves will remain imprecise because the correct references on the fully opening and closing positions are not available. During the repositioning manoeuvre the flashing is activated in a differentiated way (3 seconds on, 1.5 seconds off) to highlight that this is a special manoeuvring stage: only when the flashing returns to normal will the control unit have recovered the position references. The repositioning manoeuvre is performed at a reduced speed, as set in parameter **4 I** in extended mode.


The loss of references is caused by a blackout or the opening of the motor release or if the obstacle detection based on the encoder being activated three times at the same point, thus indicating that there is a stable obstacle on the stroke.

## 11 Extended operation mode

N.B.: if you are only using the simplified mode the value of the invisible parameters - for a control unit leaving the factory, or after a reset of the standard parameters - this is the one shown next to the parameter, and is considered to be of greater usefulness in installations.

**WARNING!** Depending on the selected mode, some parameters may not be displayed, as they do not relate to the installation.

The table for the extended mode parameters is below. The standard production value is next to the parameter number.



A2 00	Automatic reclosing after the rest time
00	OFF (doesn't automatically relock)
01-15	NUMBER of reclosure attempts (interrupted by photocell) before finally staying open
99	try to close without limitation to the number of attempts

NOTE: parameter 1- in simplified mode

To enable automatic reclosing you must set this parameter to a different number from 00; only by setting the value 99 will it always reclose after the rest time. However, if you set a number between 01 and 15, that is the maximum number of attempts at reclosing carried out. For example, by setting the value 01,

if a person crosses the ray of the reversal photocells when reclosing, the leaves would re-open but would no longer close (only performs one reclosing attempt).

Automatic locking is only performed if the leaf reaches the fully open position.

NOTE: the value of parameter 49 is subordinate to that selected for parameter A2; parameter 49 has a maximum value equal to that of parameter A2.

A3 00	Reclosing after blackout
00	OFF (does not reclose when the power is restored)
01	ON (recloses when the power is restored)

NOTA: parameter 3- in simplified mode.

If this parameter is set to 01 the control unit, when on, performs the reclosing after a pre-flashing lasting 5 s (even if not enabled on parameter A5). This feature is useful when there is no longer the supply voltage during the reclosing because it guarantees that the gate is closed when the supply voltage is restored.

<b>A4</b>	<b>00</b>	<b>PASSO-PASSO (PP)</b>
	<b>00</b>	OPENS - STOPS - CLOSES - STOPS - OPENS
	<b>01</b>	PP CONDOMINIUM, command PP refreshes the rest time from fully opened
	<b>02</b>	PP CONDOMINIUM, command PP closes from fully opened
	<b>03</b>	OPENS – CLOSES – OPENS - CLOSES
	<b>04</b>	OPENS – CLOSES – STOPS – OPENS

NOTE: parameter **5-** in simplified mode

Condominium means that the command PP is ignored when opening.

In installations where multiple users may arrive at the same time, and therefore trigger the radio control while the gate is operating, is useful to ensure the completion of the opening: it is possible to prevent two activations by different users from reversing the motion by closing the gate.

ATTENTION: by setting condominium mode (value **01** and **02**) automatically activates automatic relocking (parameter **A2**).

By setting the parameter to the value **01**, if the gate is open, the activation of the step-by-step command does not perform a closure but restarts the count of the rest time.

<b>A5</b>	<b>00</b>	<b>Pre-flashing</b>
	<b>00</b>	OFF (the flashing light is only on when there is movement)
	<b>01-10</b>	DURATION IN SECONDS of the early activation of the flashing
	<b>99</b>	not performed when opening; 5 seconds of pre-flashing when closing

NOTE: parameter **5-** in simplified mode

<b>A6</b>	<b>00</b>	<b>Condominium function with PEDESTRIAN (PED)</b>
	<b>00</b>	OFF (pedestrian control performs AP-ST-CH-ST-AP- ...)
	<b>01</b>	ON (pedestrian control operated when opening is ignored)

<b>A7</b>	<b>00</b>	<b>Man present</b>
	<b>00</b>	OFF (the controls work normally)
	<b>01</b>	ON (the gate only moves by holding down AP or CH)

The motors will only remain active in the presence of a continued command; only the commands AP and CH are enabled; the motors will stop upon release of the command.

The commands must be positioned so as to be able to check the movement of the gate.

<b>A8</b>	<b>00</b>	<b>Gate open light</b>
	<b>00</b>	when the gate is closed the light is off, otherwise it is on
	<b>01</b>	slow flashing when opening, quick when closing, fixed from fully open, turns off 3 times in succession every 15 seconds if the gate has stopped in the intermediate position
	<b>02</b>	the SC output is used to supply power to the photocells and perform the test on them

<b>11</b>	<b>15</b>	<b>Length travelled in slowdown</b>
	<b>01-30</b>	PERCENTAGE of the total stroke

If the slowdown is enabled (parameter **41** different from **00**), it determines how much space it will cover - with respect to the total - at the slowed down speed.

WARNING! If the encoder is not being used, this choice must be made before starting to programme the stroke. If it is done after programming, it will be necessary to proceed with a new programming.

13 10	Tolerance of the position in which the leaf is considered fully open or closed
01-40	rpm

Establishes the maximum tolerance in the control of the full opening and closing position (where there is a motor stop). Too narrow a setting is likely to cause the reversal of the motion when the leaf arrives at the stop.

The parameter is only visible if 1 or both limit switches are not present (72 00 or 72 02) and the encoder is enabled (75 01 or 75 02).

15 30	Pedestrian stroke length
01-99	PERCENTAGE of the total stroke

16 00	Margin of recovery for timed operation
00	3 seconds
01	seconds (useful for hydraulic motors, with higher inertia)

In the timed operation: programming the work time it is a good idea to always set a safety margin (3-4 seconds) to be sure that the manoeuvre is always complete, even when changing the weather conditions (wind, low temperature). When you reverse the motion, for example upon activation of the photocells, the activation of the motor in the opposite direction takes place for the exact time that was spent in motion plus a safety margin (recovery inertia).

In the case of hydraulic motors, with greater inertia, it is possible to increase this margin for a greater guarantee of manoeuvre completion from the standard value of 3 seconds to the increased value of 6 seconds.

The parameter is only visible if the encoder is disabled (75 00).

21 30	Pause time for automatic reclosing
00-90	SECONDS
92-99	from 2 to 9 MINUTES

NOTE: parameter 2- in simplified mode

When one of the photocells is obscured the timer is reset and the count restarts upon the return of the safety protection at pause.

22 20	Work time
00-99	SECONDS of manoeuvre

The parameter is only visible if the encoder is disabled (75 00).

24 00	Doubling work time
00	OFF (normal manoeuvre time)
01	ON (doubling of the manoeuvre time)

Used for installations with particularly long work times.

The parameter is only visible if the encoder is disabled (75 00).

27 02	Time taken to move back after the intervention of the safety edge or the anti-crushing protection
00-60	SECONDS

Establishes how many seconds the reversal operation on obstacle lasts; set to a value high enough to reach the opening limit switch it also performs automatic reclosing according to parameter 49.



<b>28 01</b>	<b>Advance activation electric lock time with respect to the manoeuvre</b>
<b>00-02</b>	SECONDS

The parameter is only visible if the electric lock is enabled (79 99).

<b>29 03</b>	<b>Electric lock duration (activation that follows the advance, parameter 28)</b>
<b>00</b>	DISABLED
<b>01-06</b>	SECONDS

If the pressure surge is enabled (para. 38) para. 29 must have a value greater than para. 38.  
The parameter is only visible if the electric lock is enabled (79 99).

<b>30 00</b>	<b>"generator" mode</b>
<b>00</b>	OFF
<b>01</b>	ON (Digital filtering for additional power from generator)

NOTE: parameter 4- in simplified mode.

Enabling this feature improves the control of the movement with power from generators.

<b>31 05</b>	<b>Torque level during normal stroke</b>
<b>01-08</b>	1 minimum force ... 08 maximum force

NOTE: parameter 9- in simplified mode.

This parameter is always minor or equal to te parameter 33.

<b>32 06</b>	<b>Torque level during slowed down stroke</b>
<b>01-08</b>	1 minimum force ... 08 maximum force

NOTE: parameter A- in simplified mode.

<b>33 08</b>	<b>Torque level during start-up</b>
<b>01-08</b>	1 minimum force ... 08 maximum force

<b>34 03</b>	<b>Soft-start ramp setting</b>
<b>00</b>	OFF (soft-start disabled)
<b>01-02</b>	soft-start
<b>03-04</b>	even softer start (only available if encoder is enabled)

A low value (01) involves rapid acceleration, while a high value (04) means reaching the operating speed more slowly, thus allowing a more gentle and gradual start of the leaf.

If the encoder is disabled (75 00) the standard production value is 02.

<b>35 08</b>	<b>Level of force during the reversing start-up from rib or encoder intervention</b>
<b>00</b>	start-up disabled: (performs with the force set by parameter 31)
<b>01-08</b>	1 minimum force ... 08 maximum force

**36 03****Duration of the start-up****00-20****SECONDS travelled with the force set for the start-up phase (parameter 33)**

The start-up manages the power of the motor in the initial phase of motion, giving the maximum torque to get the guarantee of starting the leaf; depending on the condition of use it may be useful to increase this time, for example in the case of installations in very cold climates in which there may be a risk that the structure is frozen and is difficult to set it in motion. Performed immediately after the soft-start.

**37 00****Management last stretch of stroke for hinged leaf****00****OFF****01-05****leaf length (1=0,5m, 2=1m, 3=1,5m, 4=2m, 5=2,5m)**

Setting this function, when opening decreases the torque in the latest stretch of the stroke by reducing the vibration which is generated when the leaf contacts. When closing, the operation varies on the basis of the presence or absence of the electric lock: if present (parameters 28, 29 and 79) it increases the torque to ensure the closure of the electric lock, if absent it decreases the torque to prevent vibration.

The parameter is visible only if the encoder is enabled (75 01 o 75 02).

**38 00****Pressure surge****00****DISABLED****01-04****TIME IN SECONDS**

Enabled in order to facilitate the release of the electric lock, which could be hindered by the leaf which presses on the coupling point (for example, due to the wind). The opening operation is preceded by a short closing the duration of which can be selected with this parameter.

Enabling the pressure surge and the electric lock (para. 79), automatically activates the advance by 1 second (para. 28) and lasts for 3 seconds (para. 29). This is an automatic selection, it can be varied manually. The pressure surge is only performed when starting from the fully closed position, as long as the position of the leaf is not known, or in the absence of a limit switch and encoder, it is performed with each opening manoeuvre by performing a closing movement for 1 second before opening.

The parameter is visible only if the electric lock is enabled (79 99 ).

**41 01****Slowdown selection****00****slowdown disabled****01****average slowdown****02****maximum slow-down (never select this value for 6-pole motors)****42 60****Encoder sensitivity to detect an obstacle during normal travel****43 10****Encoder sensitivity to detect an obstacle during slowed down travel****01-99****PERCENTAGE (1 = completely insensitive, ... , 99 = maximum sensitivity)**

NOTE: reversing occurs when the measured speed is lower than the value set

Selecting a low percentage value for these parameters makes obstacle detection - based on the encoder signals - less sensitive. As a factory standard it is set to a value that gives good assurances of operation under all conditions, the sensitivity is therefore quite low.

In the case of obstacle detection, the motion is immediately reversed.

WARNING! For 6-pole motors set to a value less than 60

49	00	Automatic reclosing attempts after safety edge or the anti-crushing protection intervention
	00	does not automatically reclose after the safety edge or the anti-crushing protection intervention
	01-03	number of attempts at reclosing

If the value exceeds that of parameter  $A2$ , it will be automatically considered to be equal to that of parameter  $A2$ . Only recloses after the impact if it is moved back until fully open.

50	00	Mode if photocell FT1 is interrupted when opening
	00	IGNORE, no action or FT1 not installed
	01	STOP, the gate remains stationary until the next command
	02	REVERSE IMMEDIATELY, thus closing
	03	TEMPORARILY STOP, the beam released, it continues to open
	04	INVERT WHEN RELEASED, the beam released, it reverses thus closing

51	02	Mode if photocell FT1 is interrupted when closing
	00	IGNORE, no action or FT1 not installed
	01	STOP, the gate remains stationary until the next command
	02	REVERSE IMMEDIATELY, thus closing
	03	TEMPORARILY STOP, the beam released, it continues to open
	04	INVERT WHEN RELEASED, the beam released, it reverses thus closing

52	00	With the gate closed permits opening with FT1 obscured
	00	does not permit opening
	01	permits opening
	02	OPENS WHEN IT IS OBSCURED

53	03	Mode if photocell FT2 is interrupted when opening
	00	IGNORE, no action or FT2 not installed
	01	STOP, the gate remains stationary until the next command
	02	REVERSE IMMEDIATELY, thus closing
	03	TEMPORARILY STOP, the beam released, it continues to open
	04	INVERT WHEN RELEASED, the beam released, it reverses thus closing

54	02	Mode if photocell FT2 is interrupted when closing
	00	IGNORE, no action or FT2 not installed
	01	STOP, the gate remains stationary until the next command
	02	REVERSE IMMEDIATELY, thus closing
	03	TEMPORARILY STOP, the beam released, it continues to open
	04	INVERT WHEN RELEASED, the beam released, it reverses thus closing

55	00	With the gate closed it permits opening with FT2 obscured
	00	does not permit opening
	01	permits opening
	02	OPENS WHEN IT IS OBSCURED

<b>56 00</b>	<b>With the gate completely open, recloses 6 seconds after photocell interruption</b>
<b>00</b>	OFF (photocell interruption does nothing)
<b>01</b>	the interruption of FT1 causes the closure
<b>02</b>	the interruption of FT2 causes the closure

<b>60 01</b>	<b>Brake at the end of the manoeuvre</b>
<b>00</b>	OFF (brake disabled at the end of the manoeuvre)
<b>01</b>	ON (brake at the end of the manoeuvre)

<b>61 01</b>	<b>Brake on photocell intervention</b>
<b>00</b>	OFF (brake disabled whenever a photocell intervenes)
<b>01</b>	ON (brakes whenever a photocell intervenes)

<b>62 01</b>	<b>Brake on STOP command</b>
<b>00</b>	OFF (brake disabled whenever the STOP command intervenes)
<b>01</b>	ON (brakes whenever the STOP command intervenes)

<b>63 01</b>	<b>Brake on reversal (AP-CH o CH-AP)</b>
<b>00</b>	OFF (brake disabled before reversing the motion)
<b>01</b>	ON (brakes before reversing the motion)

<b>64 05</b>	<b>Brake duration</b>
<b>01-20</b>	TENTHS OF A SECOND

Change carefully, choosing a low value to prevent the leaf from restarting, rather than braking.

<b>65 08</b>	<b>Force applied by the brake</b>
<b>01-08</b>	1 minimum force ... 08 maximum force

<b>71 01</b>	<b>Position of the motor with respect to the gap</b>
<b>00</b>	motor positioned on the LEFT with respect to the gap looking from the inside
<b>01</b>	motor positioned on the RIGHT with respect to the gap looking from the inside

NOTE: parameter **0-** in simplified mode.

Changes the direction of rotation of the motor for opening and closing, also changes the interpretation of the limit switches so as not to reverse the cables.

<b>72 01</b>	<b>Limit switch enabling</b>
<b>00</b>	no limit switch connected to the control unit
<b>01</b>	opening and closing limit switch connected to control unit
<b>02</b>	only the opening limit switch connected to the control unit

NOTE: parameter **8-** in simplified mode.



73 00	Safety edge 1 configuration
00	NOT PRESENT
01	SWITCH, only reverses when opening
02	8k2, only reverses when opening
03	SWITCH, always reverses
04	8k2, always reverses

74 00	Safety edge 2 configuration
00	NOT PRESENT
01	SWITCH, only reverses when closing
02	8k2, only reverses when closing
03	SWITCH, always reverses
04	8k2, always reverses

75 01	Encoder configuration
00	NOT PRESENT
01	OPTICAL (8 pulses per revolution)
02	MAGNETIC (1 pulse per revolution)

In the absence of an encoder, control is performed on the basis of the work time.

Most ROGER motors with an encoder use optical encoders, only the E30 series uses magnetic encoders (in case of doubt please read the instructions carefully or contact customer support).

76 00	1st radio channel configuration
77 01	2nd radio channel configuration
00	PP
01	PEDESTRIAN
02	OPEN
03	CLOSE
04	STOP
05	COURTESY the relay is only driven by the radio, it is deactivated in normal operation
06	COURTESY PP (turn light on-off) the relay is only driven by the radio, it is deactivated in normal operation
07	FLASHING LIGHT relay is controlled only by the radioreceiver, is disabled in normal operation
08	FLASHING LIGHT PP (ON-OFF Light) relay is controlled only by the radioreceiver, is disabled in normal operation

78 00	Flashing configuration
00	FIXED (the intermittent operation is carried out by the electronics of the flashing)
01	slow intermittent activation
02	slow intermittent when opening; quick intermittent activation when closing


NOTE: parameter 7- in simplified mode

the flashing starts when there is a movement phase; you can have continued activation (for flashing lights with electronics timed on-board) or controlled directly by the control unit (for flashing lights with a simple lamp).

79 02	Durata luce di cortesia
00	OFF (deactivated)
01	PULSE (brief activation at the start of each operation)
02	ACTIVE DURING THE ENTIRE OPERATION
03 - 90	SECONDS OF ILLUMINATION AFTER THE END OF THE OPERATION
92 - 98	FROM 2 TO 8 MINUTES AFTER THE END OF THE OPERATION
99	output to electric lock (use an external power supply)

80 00	Clock configuration
00	When the clock input is closed (ORO) it opens and then ignores all the commands
01	When the clock input is closed (ORO) it opens and accepts all the commands

## 90 00 Restoring standard factory values

After having displayed the number 90, press the + and - buttons simultaneously for 4 seconds, the display shows  flashing which signals a standard factory values reset has taken place (indicated next to the parameter numbers).

WARNING! After the reset, check that the parameters are adjusted to the type of installation.

n0 01	Version HW
n1 23	Year of manufacture
n2 45	Week of manufacture
n3 67	Serial number
n4 89	
n5 01	
n6 23	FW version

The serial number is obtained by combining the values of the parameters from n0 to n6. For example this table shows the values (next to the parameters, they are not default values) from which you get the serial number 01 23 45 67 89 01 23

o0 01	Operations performed
o1 23	

The number of operations performed is obtained by combining the values of the parameters from o0 to o1 and by adding 2 zeros. For example this table shows the values next to the parameters (they are not default values) from which you get the operation number 01 23 00, i.e. 12300 operations.

h0 01	Operation hours performed
h1 23	

The number of manoeuvre hours performed is obtained by combining the values of the parameters from h0 to h1. For example this table shows the values next to the parameters (they are not default values) from which you get the operation hours number 01 23 i.e. 123 operation hours performed.

d0 01  
d1 23

## Days the control unit is on

The number of days the control unit is on is obtained by combining the values of the parameters from d0 to d1. For example this table shows the values next to the parameters (they are not default values) from which you get the number 0123 i.e. 123 days of the control unit being on.

P1 00  
P2 00  
P3 00  
P4 00  
CP 00

## Password

## Change password

Storing a password enables the data to be protected in the memory, only allowing those who know it to change its value. The procedure for entering the password is as follows:

- enter the eight numbers chosen for the password in parameters P1, P2, P3 e P4
- view parameter CP: on the display: simultaneously press and hold the + and - buttons for 4 seconds. When the display flashes it means that the new parameter has been saved.

The protection is activated immediately after turning the control unit off and on again or after 30 minutes of inactivity when the display switches to standby mode.

WARNING! When password protection is enabled, the + and - buttons do not allow the value of a parameter to be changed and the parameter CP has value 01.

Unlocking parameters procedure (temporary): enter the password previously stored in parameters P1, P2, P3 e P4 then view parameter CP in the display and check that its value is 00 (protection deactivated).

You can only delete the password if you know it, by proceeding as follows: enter the password, then store the password P100, P200, P300, P400, remembering to confirm it with parameter CP.

If you have forgotten your password, you can unlock the control unit by contacting support.

## 12 Inspection

Check the response to all of the commands connected.

Check the stroke and the slowdowns.

Check the impact forces.

Check the behaviour when the safety protections intervene. When the anti-crushing protection is checked be sure to move away from the limit switch or obstacles which increase the risk of crushing.

## 13 Maintenance

Perform scheduled maintenance every 6 months by checking the condition of cleanliness and operation. If there is dirt, moisture, insects or other items, cut the power and clean the card and the container. Perform the inspection procedure again.

In the case of noticing oxide on the printed circuit consider replacing it.

## 14 Disposal

The product must always be uninstalled by qualified personnel using the appropriate procedures for the correct removal of the product.

This product comprises various types of materials, some can be recycled others must be disposed of through recycling or disposal systems provided by local regulations for this product category.

This product may not be disposed of in household rubbish. Perform a separate collection for disposal according to the methods provided by local regulations; or by returning the product to the seller when purchasing a new equivalent product.

Local regulations may include severe penalties in the event of improper disposal of this product

**Warning:** some parts of the product may contain toxic or hazardous substances, if dispersed they could cause harmful effects to the environment and human health.

